

INSTALLATION MANUAL

HONDA > CLICKS 125i/150i



SPECIFIED FOR HONDA CLICKS 125i '15 > /CLICKS 150i '18 >



1. APPLY LUBRICATING FLUID TO REMOVE THE STEEL SLEEVE. **DON'T USE ANY OIL**



2. REMOVE THE BUSH FROM THE RUBBER.



3. ADD WASHER FOR INSTALLATION.



4. INSERT WASHER INSIDE THE TOP AT INSTALLATION POINT OF SHOCK ABSORBER.



5. INSTALL THE SHOCK ABSORBER.



6. INSERT THE ORIGINAL WASHER AND NUT. (TORQUE : 16 Nm.)

