

# HUSQVARNA > FC 450 '19 >



## SPECIFICATION



### > HIGH SPEED ADJUSTABLE

High speed valve is set to active when the oil pressure is too high so the shocks will not get Hydraulic Lock.



### > LOW SPEED ADJUSTABLE

Controls the Compression Stage of the Shock to move slow 30 Clicks.



### > REBOUND ADJUSTABLE

Adjust the Rebound to Control the Spring outgoing Shock Movement, Fast or Slow depending on your needs 30 Clicks.



### > THREADED SPRING PRELOAD

Adjust the Preload of the Spring relative to the Weight of The Rider.

MG456-480TRW-19F

**1,000.-<sup>EUR</sup>**